## Technical Note Nozzle Adapter Installation



CE Shepherd Saddle Pipe Nozzle Adapters are available to match 4", 6" or 8" pipe s install. Simply drill a 2-1/2" hole in the lateral pipe, apply the proper cement (see b and the adapter then attach the adapter with two (2) each #8 stainless steel self ta	pelow) to the later
Lateral Pipe	
Saddle Pipe Use "ABS to PVC" cement Adapter Use "ABS to PVC" cement bonding Adapter to Latera #8 Self Tapping Screws	for I Pipe
CE Shepherd Company L.P.	

2221 Canada Dry Street | Houston, TX 77023 713.924.4300 (Main) | 713.928.2559 (Fax) Email: coolingtowers@ceshepherd.com

